



BatteryMole® OBD-II

support@4peaks-tech.com

Plug the BatteryMole® OBD-II monitor into your car's OBD-II diagnostic port (1996 or newer cars). You may have to do an Internet search to find where your car's OBD-II port is located. After a few seconds the unit will generate a short beep, the Blue LED will turn on and then the Green LED will start blinking. You're done,,,,, simply ignore the monitor until someday it beeps. When that happens, and it surely will, get your battery charged and tested by a qualified technician.

- Green LED - blinks when the monitor is active
- Blue LED - monitor is working properly
- Yellow LED - low charge
- Orange LED - slow start time
- Red LED - low start voltage

NOTE: All LEDs turn OFF after the engine is off for 30 minutes.